

Read the manual before use and keep it for future reference.

Regardless of use, neither the manufacturer nor the retailer is responsible for violations of laws such as drink-driving.

The results are only indicative and do not serve as a criterion for the authorization of various activities.

Powered by 2x AAA alkaline batteries


For the most accurate measurement, we recommend performing the test 2-3 times within 3 minutes between each test.

Range: 0.00 - 0.19% BAC & 0.0-1.9 g / l

Perform the test at least 20 minutes after using alcohol.


Do not eat or smoke for 20 minutes before the test.

**23792-1 Alcohol tester W-TEC Spiriter**




**BATTERY PLACEMENT**

Remove the battery cover.



Insert 2x AAA alkaline batteries.




Close the battery cover.

**USE**

Press the power button. The display lights up and an audible signal sound.

"Warm up" and a countdown from 10 to 0 are displayed. If the tester has not been operated for a long time, the sensor may be dirty, switch off the device several times if necessary.

When the device is ready, "Blow" and a countdown from 10 to 00 are displayed.



Take a deep breath and breathe continuously into the device for 3-5 seconds.

The result is displayed: from 0.02 BAC (0.2 g / l) to 0.05% BAC (0.5 g / l) "Caution" appears on the display.

From 0.05% BAC (0.5 g / l) "Danger" is displayed.



After measuring the value and displaying the result, the tester automatically shuts off after 10 seconds.

If the "warm up" of the device cannot be load, the tester switches off automatically and must be started again.

If the device is not used within 10 seconds of being ready for use, the display will show 0 for 10 seconds.

## SET TIME



While the time is displayed, press the "Adj" button to select 12 or 24 hour format.

Hold down "Set" for 2 seconds to enter the time setting. The time on the LCD display will flash. Press "Adj" to enter the time adjustment.

Press "Set" to enter the minute setting, the minutes will start flashing. Press "Adj" to adjust the value.

Press "Set" to confirm the changes.

## SET ALARM

While displaying the time, press "MODE" to enter the alarm.

Press "Adj" to turn the alarm on or off.

Hold down the "Set" button for 2 seconds to enter the setting. The hour value will flash, press "Adj" to adjust the value.

Press "Set" to enter the minute setting and "Adj" to adjust the value.

After setting the minutes, press "Set" to confirm the changes.

## TEMPERATURE

Press "Mode" twice to enter the temperature format setting.

Press the "Adj" button to select ° C or ° F.

## COUNTDOWN

While displaying the time, press "Mode" 3 times.

Hold down "Set" for 2 seconds, the hour value will flash, use "Adj" to adjust the value.

Press "Set" to enter the minute setting, press "Adj" to adjust the value.

After setting the minutes, press "Set" to confirm the changes.

Press "Adj" to start the countdown, press "Adj" repeatedly to turn off the countdown.

If the value reaches 00:00, a beep sounds and the countdown starts again.

## SPECIFICATIONS

Range:	0,00 % - 0,19 % BAC (0,0 – 1,9 g/l)
Accuracy:	-0,01 % ~ + 0,02 % at 0,05% BAC
Power supply:	2x 1,5V AAA alkaline batteries
Operating time:	Loading: 10 seconds, response: 5 seconds
Clock accuracy:	±2 seconds / den
Dimension:	100 x 37 x 17 mm