



## USER MANUAL – EN

# IN 24937 Spare battery for Baichen Omis and Kocunar 24V 12Ah mobility scooters

### SAFETY INSTRUCTIONS

- Read the manual before use and keep it for future reference.
- Do not leave the battery unattended in the presence of children or pets.
- The battery contains a chemical source of electrical energy, contains solid or liquid chemical compounds (caustics) that can cause damage to health, property, or the environment. Therefore, handle batteries with care.
- The battery, as a source of electricity, is able to supply electricity at any time in the ready state, even in undesirable circumstances! Please note that even with a partially charged battery, when both contacts (terminals) are interconnected by a conductive material (e.g. careless handling, transport, storage, etc.), a large amount of electrical energy, an so-called short circuit, is released uncontrollably. In the best case, only the battery will be damaged. In the worst case, if the phenomenon is long-term (but a few seconds are enough), it can cause a fire, even an explosion, damage to property or the environment, but last but not least, damage to human health or life! Therefore, always handle the batteries in such a way that there is no short circuit!
- Used batteries as well as old, unused, functional and non-functional batteries and cells automatically become hazardous waste after consumption, which can seriously endanger the environment if not disposed properly! The vast majority of batteries contain hazardous chemical elements or their compounds. Lead, cadmium, mercury, electrolyte (H<sub>2</sub>SO<sub>4</sub>), but also other toxic substances that are harmful to the human body. These can be released into nature and cause damage due to poor storage. Therefore, please do not dispose of used batteries and cells in the municipal waste!
- The individual batteries and starter batteries differ significantly from each other. When replacing an old battery with a new one, follow the device manufacturer's instructions or state which battery is intended for which appliance. Installation of an unsuitable battery type may result in irreversible damage or, in the worst case, damage to the vehicle or equipment.
- Charge the battery in a ventilated area. If the battery is hot to the touch, stop charging and allow it to cool. Do not handle open flames, smoke or sparks near the battery. You will learn more about security in our next article.
- Do not open the battery.
- If the battery emits smoke or you smell, stop using the battery.
- Do not use the battery if it is deformed or otherwise damaged or worn.
- You can clean the battery cover with a damp soft cloth, water must not get into the electrical contacts of the battery.
- Do not open or modify the battery, use it only for the specified product.
- Store the battery at temperatures between + 10 ° C and 20 ° C.
- Never store the battery in a discharged state.

- In the event of mechanical damage or improper handling, electrolyte leakage and contact with skin or eye, wash the affected area with a strong stream of water and seek medical attention immediately.
- Handle batteries carefully, avoid shocks and ensure that they are in the correct position during transport, operation and storage.
- To maintain the longest possible battery life, we recommend operating temperatures from + 15 ° C to + 25 ° C.

## BATTERY HANDLING

The battery must be recharged every 2 weeks if it is not used and recharged regularly. Never allow the battery to discharge completely. Prior to use, make sure that the battery is connected correctly and does not show signs of damage or wear.

## BATTERY CHARGING

**WARNING:** Always use only the original battery and charger. Using the wrong charger can damage the device.

Recharge the battery to the maximum before using it for the first time. Learn to use the mobility scooter slowly, don't drive too fast and stay close to home. Learn how to read battery information. Recharge the battery for 10 to 12 hours and then continue to use the mobility scooter. After 4 to 5 charging cycles, the battery reaches its maximum capacity.

If you do not use the cart regularly, you need to charge the battery to the maximum once every two weeks.

After discharging the battery, it is necessary to recharge it as soon as possible. If you let the battery completely discharge, you will reduce its capacity.

## BATTERY SPECIFICATIONS

Battery type	Lead acid battery
Dimensions	152 mm x 99 mm x 96 mm
Voltage	2x 12 V
Capacity	12 Ah

## CHARGER SPECIFICATIONS

Input	100-240V 50/60 Hz, 1,5 A
Output	24V, 2000 mA

Charge indicator:

- Green - battery is charged
- Blue - battery is charging

## ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyards.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

# TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

## General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

## Warranty Conditions

### Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

### Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

### The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

## Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

**CZ**  
**SEVEN SPORT s.r.o.**

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR  
Headquarters: Dělnická 957, Vítkov, 749 01  
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264  
VAT ID: CZ26847264

Phone: +420 556 300 970  
E-mail: eshop@insportline.cz  
reklamace@insportline.cz  
servis@insportline.cz

Web: www.inSPORTline.cz

**SK**  
**inSPORTline s.r.o.**

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723  
VAT ID: SK2020177082

Phone: +421(0)326 526 701  
E-mail: objednavky@insportline.sk  
reklamacie@insportline.sk  
servis@insportline.sk

Web: www.inSPORTline.sk